

## **C-28 Elctroplating Plant Fires**

## **Emergency Manual**

Date Revised: 02/01/2018

Last Modified: 09/27/2024 06:39

Export C28 to PDF
Export -Entire C Manual- to PDF

## Policy/Procedure

- **1.** During the initial scene 'size-up' of an electroplating plant fire, the incident commander shall consider requesting the response of the Haz-Mat unit.
- **2.** Fire personnel shall cover all uninvolved tanks or baths to keep water out.
- **3.** Fire personnel shall avoid throwing water into tanks if they cannot be covered.
- **4.** Fire personnel shall treat the incident as a hazardous materials spill and shall wear full protective clothing and SCBA throughout its mitigation.
- **5.** Fire personnel shall attempt to dike all spills.
- **6.** The use of fog is preferred to avoid stirring up dust and grinding operations and/or overfilling of acid baths.
- **7.** Fire personnel shall de energize equipment only after consultation with a foreman or maintenance man familiar with the plant. Crews shall not shut-off gas without consultation with building maintenance.
- 8. Fire personnel shall endeavor to cool all exposures.
- **9.** Fire personnel shall utilize extreme caution during overhaul, as there are a great number of caustics present at these facilities. Full protective clothing shall be worn through the entire overhaul process.

See Also:

Permanent link:

https://www.tfrdweb.com/dokuwiki/doku.php?id=c\_manual:c28

Last update: 09/27/2024 06:39

