

## C-43 Fuel Oil Tank Leaking - Domestic

## **Emergency Manual**

Date	Revised:	02/01	/2018

Last Modified: 09/27/2024 09:45

Export C43 to PDF
Export -Entire C Manual- to PDF

## Policy/Procedure

- **1.** If a domestic fuel oil tank is leaking, crewmembers shall first shut off the emergency switch to the burner.
- **2.** Fire personnel shall then close the oil supply valve to the burner.
- **3.** If available, crewmembers shall utilize an emergency tank repair kit to stop the leak.
- **4.** If the leak is serious, fire personnel shall shut off and/or remove all sources of ignition until all the oil can be picked up. If there is a floor drain present, it should be sealed off.
- **5. NOTE:** It is the owner's responsibility to remove/clean-spilled oil. Crew members shall not clean up spilled oil.
- **6.** The Incident Commander shall update Dispatch and direct Dispatch personnel to contact Environmental Services and/or the Sewer Department.

See Also:			

Permanent link:

https://www.tfrdweb.com/dokuwiki/doku.php?id=c\_manual:c43

Last update: 09/27/2024 09:45

